


Pinza porta Hileras de Roscar de cambio rápido
Die holder adaptor



SEF



REFERENCIA	TIPO	B X E	X	H	K	D	B
SEF1-16x5	1	16 x 5	19	21.5	14	25	16
SEF1-20x5		20 x 5			14	30	20
SEF1-20x7		20 x 7			16	30	20
SEF1-25x9		25 x 9			19	35	25
SEF1-30x11		30 x 11			21	40	30
SEF1-38x10		38 x 10			20	48	38
SEF1-38x14		38 x 14			24	48	38

REFERENCIA	TIPO	B X E	X	H	K	D	B
SEF2-20x5	2	20 x 5	31	35	20	40	20
SEF2-20x7		20 x 7			21.5	40	20
SEF2-25x9		25 x 9			23.5	40	25
SEF2-30x11		30 x 11			22	40	30
SEF2-38x10		38 x 10			21	48	38
SEF2-38x14		38 x 14			25	48	38
SEF2-45x14		45 x 14			25	57	45
SEF2-45x18		45 x 18			29	57	45

REFERENCIA	TIPO	B X E	X	H	K	D	B
SEF3-30x11	3	30 x 11	48	55.5	30	60	30
SEF3-38x10		38 x 10			28	60	38
SEF3-38x14		38 x 14			32	60	38
SEF3-45x14		45 x 14			32	60	45
SEF3-45x18		45 x 18			36	60	45
SEF3-55x16		55 x 16			30	72	55
SEF3-55x22		55 x 22			35	72	55
SEF3-65x18		65 x 18			32	82	65
SEF3-65x25		65 x 25			38	82	65